

Model ERV-Rooftop Configuration



Model ERV-Open View



Shown with removable Enthalpy Energy Wheel and Filter Bank.

Microprocessor Controller



*Located in unit control center.
Permits direct input without ancillary hardware or software.*

Remote Interface



*Used with Microprocessor Controller.
Input new operating settings and displays alarm conditions.*

**Remote Control Panel
Shown with timer.**



**CO2 Sensor
Duct Mounted**



**CO2 Sensor
Room Mounted**

